

Foucault Pendulum Electronics Kit.

D99_Errata.

www.foucaultpendulum.nl

Document version	2026-05-20
Relates to PCB version	All
Related Documents	All

On the Receivers PCB the traces for TP5, TP6, TP11, TP12, TP17 and TP18 are missing. They are on the schema but not on the board.

The remedy: Take 6 pieces of cutoff wires from resistors, bend an eyelet of a few mm diameter on one side, put it in the TP-hole, and solder it on the bottom side to the cathode of the adjacent diode. The eyelet can be used to hook an oscilloscope probe for testing.

The text near the 4x2 option jumper block on the BobControl PCB should read OPT1-4.